

#1232: HyperView – Measure Radius

Product: HyperView

Product Version: HyperView 2017 or above

Topic Objective

Measure Radius in HyperView

Topic Details

A new measure type is added to calculate the radius and center of the circle based on three nodes. Similar to other measures, the circle is updated and values are re-computed for every step of the animation. Options to plot the measure as a curve, compute it in a different system are available.

Calculate radius and center of the circle

- Input: three nodes or systems
- Calculates across all steps of the animation
- Plot measure in Hypergraph

